



MISCELLANEOUS HOUSE EQUIPMENT

| QUANTITY | TYPE | DIMENSIONS |
|----------|---------------------------------|---|
| 2 | Stairs | 24" (T) x 53" (L) (Rise 8" x 10" Run- 3 steps) |
| 2 | Stairs | 35" (T) x 60" (L) (Rise 7" x 12" Run- 5 steps) |
| 1 | Stairs | 16" (T) x 20" (L) (Rise 8" x 10" Run- 2 steps) |
| 1 | Stairs | 16" (T) x 18" (L) (Rise 8" x 9" Run- 2 steps) |
| | | |
| 2 | Balcony Rail Projector Platform | 26" (w) x 32" (d) |
| | | |
| 61 | Music Stands | |
| | | |
| 8 | Risers | 4' x 8' x 8" |
| 6 | Risers | 4' x 8' 16" |
| 5 | Risers | 4' x 8' x 24" |
| | | |
| 7 | Pit Carpet | Specific Cut to Fit the Pit Floor - Black |
| | | |
| 3 | Riser Carpet | 8'x8' |
| 6 | Riser Carpet | 4'x8' |
| 1 | Riser Carpet | 8'x16' |
| 6 | Misc. Carpet Cuts | 5'x7' (Gray), 5'x8.5' (Blue), 5'x10' (Gray), 6'x8' (Med Gray), 3'x12' (Dark Gray), 6'x8' (Gray Black), 9'x12' (Brown) |
| | | |
| 4 | Flats | 4' x 8' Quick Change Hinged Panels |
| 1 | Flats | 4' x 10' Quick Change Panels |
| | | |
| 5 | Marley Strips | 6'7" Wide x 65'4" Long |
| 1 | Marley Strip | 6'7" Wide x 58' Long= This piece fits around side speaker stacks |
| 1 | Marley Strip | 6'7" Wide x 64'6" Long= Best used Up Stage |

There are a total of 6 strips of Marley, but only 5 pieces will be needed to cover the entire stage.